

Connect Chromebook to SMART or Dell Display

While casting may be an option, it can be very unreliable. Therefore, the Technology Services department recommends a direct connection through an HDMI cable.

The New Dell Chromebooks:


The new teacher/student Chromebooks come with a USB-c connection instead of a regular HDMI port. To connect to the display a USBc to HDMI adaptor will be required (personal or campus purchased). From the Technology Catalog:



Stock #	Vendor	Unit Price	UOM	Long Description
55-00-0044	28806	19.00	EACH	ADAPTER - C2G USB 3.1 USB TYPE C TO HDMI ADAPTER-USB C TO HDMI BLACK - TAA = EXTERNAL VIDEO ADAPTER - USB-C 3.1 - HDMI - BLACK QUOTE 3000037844844.1

Changing Inputs: (SMART)


Tap the input button once to bring up the input menu.



Tap it again to select the next input available.


*Note: This menu is not touch-sensitive.

HDMI1 or HDMI2 (depending on which port the cable is plugged in): Select this input to mirror your Chromebook to the display.



Changing Inputs: (DELL)

Press the Source button on the remote to change to the correct input



Mirror the Display:

The Chromebook may start in a *Unified Display* mode (1 screen spread over 2 displays). The ideal setting is a *mirrored internal* display.

1. Click the three dots (top right corner) and select Settings
2. Select Device
3. Select Displays
4. Toggle off "Allow windows to span displays"
5. Check Mirror Internal Display

